






1.7  ø12	1.6  ø1	1.8  ø12	1.3  0.02	1.32  ø41
1.36  ø1	1.33  ø1	1.18  ø1	1.5  ø2	

Achtung!!!

Unbedingt Wandbefestigung (Teile 1.18, 1.33, 1.36) verwenden!

Attention!!!

Il est absolument nécessaire d'utiliser la fixation murale
(1.18, 1.33, 1.36)!

1	Beschlag / Ferrure		1
2	882*	145	2
3	600*	172**	1
4	600*	172**	1
5	270*	130	10
7	882*	145	1
6	910	288/3	2



VCM.

seit 30 Jahren
service@vcm-gruppe.de


Aufbauanleitung

Artikel:


VCM CD/DVD Möbel "Galerie"




1



2



3



4

1.54

1.54

1.54

1.54

